# **EcoLine® Cutting Fluid**





### **PRODUCT DESCRIPTION**

EcoLine Cutting Fluid is a multifunctional biodegradable concentrate for metal cutting operations. This liquid cools the work pieces and tools, prevents welding of metals during the metalworking process and provides excellent corrosion protection and lubrication during the cutting process.

High-performance characteristics make EcoLine Cutting Fluid ideally suited for heavy-duty cutting, milling, turning, drilling, broaching and other machining operations.

EcoLine Cutting Fluid is packaged in a pre-diluted "ready-to-use" 16 oz. bottle with squirt top application. EcoLine Cutting Fluid is also available in bulk concentrate, packaged in 5 gallon pails and 55 gallon drums. The EcoLine bulk concentrate can be diluted from 1:40 to 1:20.

When added to water in the ratio of 1:40 to 1:20, EcoLine Cutting Fluid gives a stable emulsion which provides excellent cooling and little or no smoke during use. This concentrated fluid can be used in small amounts providing cost savings. When used as directed, EcoLine Cutting Fluid prevents corrosion during in-plant processing, storage, and export shipment for up to 12 months.

EcoLine Cutting Fluid has been certified as a USDA certified biobased product and has been awarded USDA BioPreferred<sup>SM</sup> designated for Metalworking Fluids for Federal Preferred Purchasing (www.biopreferred.gov)

# **FEATURES**

- USDA Certified BioBased product
- Contains 64% biobased content
- USDA BioPreferred<sup>SM</sup> designated Metalworking Fluid (general purpose and high performance) for Federal Preferred purchasing
- Environmentally friendly and biodegradable
- Replaces hazardous mineral oil

- · Excellent for operations which require rapid cooling
- Contains no chlorinated compounds, chromates, or nitrites
- · Low to no smoke or burning vapors
- Excellent anti-wear properties
- Excellent lubricity
- Excellent extreme pressure properties
- Cleans parts by removing rust and oil
- Provides excellent corrosion protection
- Displaces water and oil from metal surfaces
- Economical can be diluted 1:40 with water

### **APPLICATION**

Add EcoLine Cutting Fluid to water using a high dispersion-mixing blade. Mix for 5-10 minutes. The emulsion should remain stable indefinitely. In case of separation, emulsion can be remixed.

# **TYPICAL APPLICATIONS**

- Lubricant for heavy-duty rolling, grinding, extruding, stamping, and cutting
- In-plant machining
- Biodegradable preservative for hot-rolled, cold-rolled, galvanized, and aluminized steel during operation, storage, and shipment
- Hydrostatic testing
- Machining coolant

### **TYPICAL PROPERTIES**

Appearance Clear amber liquid

Non-volatile Content 89-93%

pH 8.5-9.3 (1% aqueous)

Density 7.8-7.9 lb/gal (0.93-0.95 kg/l)



### **TEST RESULTS**

ASTM D 1748 (Humidity Chamber) Pass 220 hours (for 2.5% solution) Pass 800 hours (for 5% solution)

ASTM D 4627-86 (Cast Iron Chip Test) Pass (1% solution)

ASTM D 2670 (Falex Pin and VEE Block Wear Test)

Conditions:

Run in/5 min. 350 lb (159 kg) Gage load/15 min. 900 lb (408 kg)

<u>Results:</u>

Total Teeth Wear 17 (2.5% solution)

10 (5% solution)

Seizure (Yes/No) No (2.5% solution)

No (5% solution)

**Tapping Torque Test** 

Specimen Type 1215 steel Speed (high speed taps) 400 rpm

Conventional Cutting Fluid 6.257 (2.5%)

6.195 (5%)

EcoLine Cutting Fluid 5.962 (2.5%)

5.814 (5)

### STORAGE AND PACKAGING

EcoLine Cutting Fluid is packaged in 16 oz. (455 ml) ready-to-use, 5 gallon (19 liter) pails concentrate, 55 gallon (208 liter) drums concentrate, liquid totes, and bulk. The product should be stored sealed. Agitate before each use. The shelf life of EcoLine Cutting Fluid is up to 24 months, it is freeze/thaw stable

<u>Note:</u> Please see the Safety Data Sheet (SDS) for proper handling of the product.

# FOR INDUSTRIAL USE ONLY KEEP OUT OF REACH OF CHILDREN KEEP CONTAINER TIGHTLY CLOSED NOT FOR INTERNAL CONSUMPTION CONSULT SAFETY DATA SHEET FOR MORE INFORMATION

### LIMITED WARRANTY

All statements, technical information and recommendations contained herein are based on tests Cortec Corporation believes to be reliable, but the accuracy or completeness thereof is not guaranteed.

Cortec Corporation warrants Cortec® products will be free from defects when shipped to customer. Cortec Corporation's obligation under this warranty shall be limited to replacement of product that proves to be defective. To obtain replacement product under this warranty, the customer must notify Cortec Corporation of the claimed defect within six months after shipment of product to customer. All freight charges for replacement products shall be notify but customer.

Cortec Corporation shall have no liability for any injury, loss or damage arising out of the use of or the inability to use the products.

BEFORE USING, USER SHALL DETERMINE THE SUITABILITY OF THE PRODUCT FOR ITS INTENDED USE, AND USER ASSUMES ALL RISK AND LIABILITY WHATSOEVER IN CONNECTION THEREWITH. No representation or recommendation not contained herein shall have any force or effect unless in a written document signed by an officer of Cortec Comparation.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE. IN NO CASE SHALL CORTEC CORPORATION BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.



Distributed by:

4119 White Bear Parkway, St. Paul, MN 55110 USA Phone (651) 429-1100, Fax (651) 429-1122 Toll Free (800) 4-CORTEC, E-mail info@cortecvci.com Internet http://www.cortecvci.com

printed on recycled paper 100% post consumer
Revised: 12/17/13. Cortec Corporation 2001-2013. All rights reserved. Supersedes: 7/18/12.
© 2013, Cortec Corporation. All Rights Reserved. Copying of these materials in any form without the written authorization of Cortec Corporation is strictly prohibited. ISO accreditation applies to Cortec's processes only.